


PORTAFUSIBLES Distribution Fuse Blocks



Eliminates multiple power supply leads from the battery.
Provides circuit protection for each amplifier in the system.
Inputs accept up to 4 GA cables; outputs accept up to 8 GA wire.
<i>DFB4</i>
1 input-4 outputs; includes two additional terminals on the input side
<i>DFB3</i>
1 input-3 outputs
<i>DFB2</i>
1 input-2 outputs